

AirStick v1.0.0
Bootloader v1.0
27.12.2016

Changes :

- Initial release, Basic version only

AirStick v1.0.1
Bootloader v1.0
28.02.2017

Changes :

- AR-242 fixed issue on f_seek overflowing sessin file
- AR-287 fixed issue on new session creation with reader name overflowing maximum allowed dimension
- AR-286 runtime printing when a tag is read can be configured by means of Runtime print enable configuration flag
- AR-196 VID can be edited or not once inserted depending on Enable/Disable VID editing configuration flag
- GPS support added
- WiFi support added, emailing of a session
- data collection support added
- ISO14223 first implementation (FDXB only)

AirStick v1.0.2
Bootloader v1.0
19.05.2017

Changes :

- AR-309 Green LED timing revised
- AR-308 Shut down timing revised
- AR-167 VID editable setting added to S-ID configuration
- AR-320 VID default can be enabled via S-ID configuration
- AR-287 Reader name can be up to 10 letters
- AR-284 Reading session name revised
- AR-159 BT scan made interruptable
- AR-314,AR-291 Verification of continuos reading, no actions taken
- AR-285 Printing shortcut on main display added
- AR-208 Wrong static reader detection caused the reader to stop while continuous reading mode, fixed
- AR-192 Single EID can be removed from a session
- AR-305 The last tag read is displayed on main screen when coming back from submenus
- AR-304 Transponder details can be inserted/modified even for duplicated readings
- AR-321 Firmware update process verified, no actions

AirStick v1.0.3
Bootloader v1.0
28.07.2017

Changes :

- AR-340 Vibration notification
- AR-339 Audio notification
- AR-360 USB KWG issue fixed

- AR-363 printing in both SPP and KWG
- AR-343 sending EID only over SPP (configurable)
- AR-366 Counter issue fixed
- AR-356 Search sets the reader in duplicates not allowed mode
- AR-342 Date and time language updated
- AR-368 USB host messages updated
- AR-354 EID format message updated
- AR-357 LED handling for continuous mode, session almost full
- ----- Reader in sleep mode if charger connected
- AR-352 First boot wizard skip button added
- AR-341 Date validation added to date set functionality